

HOT OVEN CHAIN APPLICATION GUIDE



HOW TO APPLY HOT OVEN CHAIN LUBRICANTS

- Apply at oven temperatures between 200° F (121° C) to 300° F (149° C)
- Shut off all burners in immediate area of lubrication/application.
- Exhaust fans must be running.
- Steam dampers must be open before and during lubrication.
- Keep heat on in oven until all carrier is driven off.
- Ventilation should continue until all vapors are exhausted.
- Make sure that container is closed tightly when not in use.
- Store in a safe place.
- Do not dilute lubricant.

Information and recommendations presented in this product sheet is considered reliable, but conditions and methods of use that are beyond our control my modify results and performance. The user assumes the risk and liability for loss, damage or injury arising from the application of good furnished.

07/11



ASBURY GRAPHITE MILLS, INC.

405 Old Main Street • PO Box 144 • Asbury, New Jersey 08802 Phone: 908.537.2155 • Fax: 908.537.2908

www.asbury.com